



# APPLICATION GUIDE FOR TERT-BUTYL ACETATE CLEANING PREP FOR POLISHED METALS PRIOR TO APPLICATION OF CERAKOTE CERAMIC CLEAR (MC-160)

## Compliance with all preparation steps necessary for maximum adhesion and performance of this material.

- 1) Remove all coatings, oils, polishing rouge and contaminants from the substrate by liberally and repeatedly spraying the substrate with *tert*-butyl acetate and then wiping with a clean lint-free, micro fiber rag. This process should be repeated, flooding the surface with *tert*-butyl acetate and then wiping with a clean lint-free, micro fiber rag, until no residue is observed on rag.
- 2) MC-160 is ready to spray and should not be thinned. Gently shake the container and pour through a 145 mesh filter into an Iwata LPH-80 spray gun. The use of a 0.8 mm spray tip will yield a sufficiently narrow pattern that will aid in coating hard to reach areas without excessive build up in surrounding areas. Electrostatic application may also be an option.
- 3) A 0.5 to 1.0 mil dry film thickness is recommended. To achieve this dry film thickness, a single wet coat is recommended. Spray from the most difficult surface area to the easiest. This will aid in reducing runs or excessive build up.
- 4) Allow to air dry. Parts will be tack free after approximately 35-45 minutes. Until this point, the coating is still wet and should not be touched. Parts will be partially cured after 24 hours and fully cured 5 days after application.
- 5) Finished goods may be handled, packaged and shipped after 24 hours, when the coating is partially cured, provided that breathable packing material is used.
- 6) Clean tools and equipment with *tert*-butyl acetate.
- 7) Clean Micro Fiber Rags by washing in warm or hot water with mild detergent. Do not use alkaline containing detergents. Do not use fabric softener, it will clog the open spaces in the microfiber that do the cleaning, rendering the towel useless. Avoid washing with anything made of cotton. Wash microfiber only with other microfiber. Dry on low heat or no heat and only dry with other microfiber products.

*Please contact a Cerakote® technician with questions on proper use and/or application. Onsite or offsite training courses are available for further instruction. Consult your SDS for proper handling, disposal, and precautions while using this product.*

NIC Industries, Inc. does not warranty the use or application of the materials it manufactures or supplies. Our only obligation shall be to replace any defective materials supplied by us or refund the original purchase price of that product after we have determined the product to be defective. We assume no liability for damages of any kind and the user accepts the product "as is" and without any warranties, expressed or implied. The suitability of the product and/or intended use shall be solely the responsibility of the user.

The information contained in this bulletin we believe to be correct to the best of our knowledge and testing. The recommendations and suggestions herein are made without guarantee or representation as to results. We recommend that you make adequate tests in your laboratory or plant to determine if this product meets all your requirements.